


Adjustable Collar Assembly

1. ↘



2. ↗

1. Thread the end through the leash ring.
2. Push the buckle together until it "snaps."